

Installation Guide - For Thumb-Turn Privacy

Door Prep	Door Jam	Door Prep for Victoria Plate	Door Jam for Victoria Plate
<p>1" Dia. Edge Bores</p> <p>2-1/4" Deep</p> <p>1/8" Deep</p> <p>2-1/4"</p> <p>1"</p> <p>2-3/8" or 2-3/4"</p> <p>2-1/8" Dia. Bore</p> <p>3-3/8"</p> <p>7/8" Dia. Bore</p> <p>SEE INSTALLATION TEMPLATE</p>	<p>1/8" Deep</p> <p>1-1/4"</p> <p>1/8" Deep</p> <p>2-1/4"</p> <p>1"</p>	<p>1" Dia. Edge Bores</p> <p>2-1/4" Deep</p> <p>1/8" Deep</p> <p>2-1/4"</p> <p>1"</p> <p>2-3/8" or 2-3/4"</p> <p>7/8" Dia. Bore</p> <p>3-3/8"</p> <p>2-1/8" Dia. Bore</p> <p>SEE INSTALLATION TEMPLATE</p>	<p>1/8" Deep</p> <p>2-1/4"</p> <p>1"</p> <p>1/8" Deep</p> <p>1-1/4"</p>

Inside

Remember to install Plastic Alignment Device

Outside

Tailpiece Horizontal